>> ELECTRON TREATMENT OF SEED <<

- an environmental friendly treatment method with future potential -



Post-Neonikotinoid-Symposium 01. Dezember 15, Berlin, Germany

Fraunhofer Institute for Organic Electronics, Electron Beam and Plasma Technology FEP

Dresden, Germany



Content

Fraunhofer FEP

How does it work

History – 25 years of electron treatment






Fraunhofer FEP Fraunhofer-Gesellschaft

- is Europe's largest application-oriented research organization
- was set up in 1949
- 66 institutes and independent research units with 22,000 employees all over Germany
- the headquarters is located in Munich
- each institute has its own core competences
- the individual institutes act as profit centers on the market









Fraunhofer FEP **Facts and Figures**

Employees: 193

Total budget: 25.8 M€

Industry returns: 8.3 M€

Public funding: 9.0 M€

Investments: 2.3 M€

(March 2015)

Director

Prof. Dr. Volker Kirchhoff

















Fraunhofer FEP

How does it work

History – 25 years of electron treatment








How does it works

Basics: Electron speed and interactions

- Acceleration of electrons up to a speed of 10^8 m/s
- The kinetic energy of the electrons is converted in the substrate










How does it work

Biocidal effect




How does it works

Basics: Penetration depth


$$-\left(\frac{dE}{dx}\right)_{ges} = -\left(\frac{dE}{dx}\right)_{Koll.} - \left(\frac{dE}{dx}\right)_{Str.} - \left(\frac{dF}{dx}\right)_{Paar} - \left(\frac{dF}{dx}\right)_{Photo} - \left(\frac{dF}{dx}\right)_{Comp.} - \left(\frac{dF}{dx}\right)_{Hadr.}$$


- Electrons interacts with the material
 - Ionization of atoms
 - Excitation of electrons
 - Bremsstrahlung
- Limited penetration depth
 - Acceleration voltage
 - Density and thickness



How does it works

Adjustment of machine





$$S \approx 6.67 * 10^{-11} * \frac{(U_B * k_1)^{\frac{5}{3}}}{\rho} * k_2$$

Quelle: Schiller, Heisig, Panzer: "Elektronenstrahl-Technologie"; FEP, 1995


- Calculation of acceleration voltage, depending on
 - Seed shell thickness and density
 - Distance to emitter
- Calculation of current, depending on
 - Aimed dose





How does it work

Basic principle





Fraunhofer FEP

How does it work

History – 25 years of electron treatment





History – 25 years of electron treatment Motivation

- Using of mercury based seed treatment agents was the common practice until the 80th
- Increasing problems with mercury residues in food caused by heavy metal accumulation in soil
- Special economical situation in the former East Germany
- Development of new chemical agents was very expensive
- Searching to new alternative technologies
- Biocidal effect of ionized radiation is well known since 1905
- But penetration sensitive method is necessary, because the embryo has to be untouched
- X-ray and gamma radiation are unfeasible therefore
- First idea of using accelerated electrons was tried 1980 at the private Research institute Manfred von Ardenne




History – 25 years of electron treatment First testing equipment

- ■Electron treatment system ELBA 50
 - 1 Scanned electron beam 50 kV
 - **1983**
 - 5 kg batch treatment in rotary screen
 - Wheat treatment under vacuum



- ELBA 60-1
 - 1 Scanned EB 60 kV
 - 1987 Weinböhla
 - Semi-Batch treatment in vacuum in rotary screen









History – 25 years of electron treatment Testing equipment for continuous treatment

- Pilot plant WESENITZ 1
 - 2 Scanned EB, 60 kV
 - **1995**
 - Continuous treatment in vacuum
 - Throughput: 10 t/h







History – 25 years of electron treatment Pilot plant

1997: Electron treatment with industrial-like throughput



- Mobile treatment plant WESENITZ 2 (FEP)
 - 2 line emitting sources,145 kV
 - Continuous treatment on air
 - Throughput: 30 t/h



History – 25 years of electron treatment Technology today

More than 10 years successful industrial pilot operation.

June 2011 selling the pilot plant to BayWa and Nordkorn for real farming use.







André Weidauer

Fraunhofer Institute for Organic Electronics, Electron Beam and Plasma Technology FEP Winterbergstr. 28 01277 Dresden / Germany

Tel.: +49 (0) 351 2586 – 164

Fax.:+49 (0) 351 258655 - 164

Andre.Weidauer@fep.fraunhofer.de

seed-health@fep.fraunhofer.de>



